

# TAKACAT

## GO SERIES BEACH WHEELS FITTING INSTRUCTIONS

You will need a 7mm drill bit and some timber to place on the opposite side of the transom as a backing when drilling your holes.

1. Line up the brackets as shown in the picture. They should be a minimum of 10mm off the base of the transom and on the inside edge of the transom.
2. With a pencil / marker pen mark your four drill holes.
3. Drill the four 7mm holes taking care when drilling on to your backing board.
4. Using a tube of Selleys Marine Sealant RTV seal the holes and thread the Allen Head and washer through from the inside of the boat. Mounts your bracket using a small amount of sealant to seal around the holes. Fit the washer and the lock nut and tighten up.
5. Your Ready to go.
6. Stow your beach wheels upwards and outwards when not in use.
7. Invert them for retrieving and launching.

